

## D. FUEL JETS & AIR BLEEDS LOCATIONS

1. Main jet plugs & gaskets
2. Primary main jet & gasket
3. Primary slow air bleed no.1 & slow jet
4. Accelerator pump inlet seat screw
5. Accelerator pump inlet weight
6. Accelerator pump inlet check ball
7. Primary slow air bleed no.2
8. Primary main air bleed
9. Pump nozzle bolt & gasket
10. Accelerator pump outlet weight
11. Accelerator pump outlet check ball
12. Primary main air bleed
13. Primary slow air bleed no.2
14. Primary slow air bleed no.1 & slow jet
15. Primary main jet & gasket
16. Main jet plugs & gaskets
17. Secondary slow air bleed no.1 & slow jet
18. Secondary main air bleed
19. Secondary slow air bleed no.2
20. Secondary main air bleed
21. Secondary slow air bleed no.2
22. Secondary slow air bleed no.1 & slow jet
23. Power valve & gasket
24. Richer air bleed & jet
25. Richer air bleed no.2 - or plug

