


**1720-1 CHANGE CONTROL SYSTEM (MANUAL)  
(W/O TURBO)**



6C01 FC33\* -525576

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODE/DESCRIPTION	REMARKS
	17 351A	PIN, INTER LOCK	0114-17-351	2		
	17 402	FORK, SHIFT (1ST & 2ND)	M502-17-402A	1		
	17 404	FORK, SHIFT (3RD & 4TH)	M501-17-404B	1		-6C01
	17 406	FORK, SHIFT	M504-17-406A	1		
	17 410	ROD, SHIFT (1ST & 2ND)	M502-17-411A	1		
	17 410A	END, S/ROD (1ST & 2ND)	M501-17-412	1		
	17 411	SPRING, SHIFT ROD	0103-17-411	2		
	17 411A	SPRING, SHIFT ROD-REVERSE	0014-17-411	2		
	17 420	ROD, SHIFT (3RD & 4TH)	M503-17-421	1		
	17 422A	ROD, S/ROD (3RD & 4TH)	M501-17-422	1		
	17 431	ROD, SHIFT-OVERTOP & REVERSE	M505-17-431A	1		
	17 432	END, SHIFT	M501-17-432	1		
	17 460	LEVER, SHIFT	M512-17-460	1		
	17 461A	END, CONTROL LEVER	M505-17-461A	1		
	17 465C	SPRING, SELECT	M501-17-465B	1		
	17 470	CASE, CHANGE CONTROL	M508-17-470D	1		
	17 474A	CAP, SPRING	M501-17-474	1		
	17 475	BOOT, DUST-CHANGE LEVER	M509-17-480A	1		
	17 475A	GASKET, SPRING CAP	M501-17-475	1		
	17 476	SPINDLE, SELECT LOCK	M502-17-476A	1		
	17 477	SPRING	M501-17-477	1		
	17 481A	BUSHING, CHANGE	M508-17-481A	1		
	17 482	WASHER, WAVE-CHANGE CONTROL CASE	M505-17-482	1		
	17 483	SPRING	8599-17-482	1		
	17 486A	COVER, BLIND	0824-17-483	1		
	17 490A	COVER, ROD	M501-17-486A	1		
	17 491B	CAP, SPRING	M502-17-490A	1		
	17 510	LEVER, CHANGE	0183-17-491	1		
	17 520	KNOB, CHANGE LEVER BLACK	M515-17-510A	1		
	17 524	NUT, LOCK	M507-17-520 00 M503-17-524A	1		