

Parts List					Factory Service Manual			
Description	Comments	Part Group	Part Number	Qty	FSM Diagram	ECU Code (F-222)	Inspection Notes	
Solenoid	<i>Solenoid F: Charge Control</i>	13-240 (#1)	1480-13-240A	3		45	F-177	\$49.88
	<i>Solenoid G: Double Throttle</i>					50	F-177	
	<i>Solenoid H: Charge Relief</i>					46	F-177	
Solenoid	Solenoid A: Pressure Regulator	13-240 (#2)	1481-13-240A	1			F-177	\$49.88
Solenoid	<i>Solenoid B: Relief 1</i>	13-420 (#3)	1482-13-240A	2			F-177	\$49.88
	<i>Solenoid D: EGR</i>					28	F-177	
Solenoid	<i>Solenoid C: Switching (ACV)</i>	18-740A (#1)	N3A7-18-741	1			F-177	\$53.13
Solenoid	<i>Solenoid E: Turbo Control (Pressure)</i>	18-740A (#2)	N390-18-741	1		44	F-177	\$53.13
Solenoid	Purge Control Solenoid	18-740E	F285-18-741	1		40	F-131	\$53.88
Solenoid	Turbo Control Solenoid (Vaccuum)	18-740B	N3A1-18-741	1		44	F-176	\$53.13
Solenoid Pair	<i>Wastegate / Precontrol Solenoids</i>	20-285	N3A1-20-285	1		43 / 42	F-93	\$118.63
Check Valve (Green/Black)	<i>Turbo Control (Vacuum)</i>	13-995 (#3)	N390-13-995A	2			F-90	\$22.50
	<i>Turbo Control (Pressure)</i>						F-90	
Check Valve (Grey/Black)	PCV	13-890 (#1)	NF01-13-890	1			F-124	\$15.50
Check Valve (Metal)	Purge Control	13-890 (#2)	N3A1-13-890	1			F-132	\$15.50
Check Valve (Green/White)	<i>Switching</i>	13-995 (#1)	HE41-13-995	2			F-139	\$24.06
	<i>Double Throttle</i>						F-139	
Vacuum Chamber		20-339 (#1)	N3C1-20-339	1				\$81.00
Pressure Chamber		20-339 (#2)	N3C2-20-339	1				\$81.00