



Stock MAP sensor may be used with E6K/E11 as a 2BAR sensor. 12v turn-on must be supplied to sensor.

<b>K2RD</b>	RX7 FC3S (86-88) MAP Sensor			
	DATE 03/18/2003	DRAWN PK	SHEET <b>E6K/E11</b>	DWG NO. <b>P01</b>
	APP	REV		